

DUST CLEANER

DEFINITION

The DUST CLEANER BLADE is a highly useful tool for the elimination of nibs and runs/sags on painted surfaces. It is a small block made of a special material, ground on all eight sides, which allows you to "shave" the nib or run without damaging the surrounding area.

The hole in the blade is designed so that it can be hung around the user's neck, preventing drops that could damage the blade edges.

Available in three versions:


- For Curves 85840: perfect for working effortlessly on angles, wheel arches, or joints, where the flat surface blade cannot reach.
- For Flat Surfaces 85850: ideal for the majority of defects on flat surfaces.
- Ceramic 85850LC: for flat surfaces, features a greatly reduced risk of chipping; guarantees exceptional durability and an even cleaner and more precise cut, ideal for delicate or serial processing.

INSTRUCTIONS FOR USE

Place the widest part of the blade flat against the painted surface and, **without applying pressure**, gradually cut the nib or run.

With a little practice, it will also be possible to use the blade in an inclined position, utilizing one of its narrow sides.

IMPORTANT: only use the blade on perfectly dry and hard paint finishes.



STORAGE

Store the product in a cool and dry place in its original packaging. Avoid dropping it, as this could damage the blade edges; clean thoroughly after each use.

The effectiveness of our products is based on practical experiences and research work carried out in our laboratories; nevertheless we accept no liability for work carried out following our instructions being clear that the final result depends in all cases on a series of unforeseeable factors.

* For any information about product codes or packs, please see our catalogue, our price list or contact us.